



UPDATE FIRMWARE_V17.03_100167

STEP1 Open the upgrade program, Press the "Update" button



STEP2 Press and hold the pairing button "SYNC", and then connect Micro USB to PC.
You can lose the pairing button "SYNC" when "Connect State: Connected" shows on the screen and the LED is off.



STEP3 (Please do not remove Micro USB during upgrading.)

When the upgrade progress is up to 100%(also you will see "Please unplug device!" on the screen), your Micro USB can be removed.

